

ACTIVE CLEANER 01

TENSIDE CLEANER FOR CLEANING ALL SOLID SURFACES

Removes oil residues from tools
Easily removes dirt films and oily residues of all kinds.

For cleaning of all solid surfaces - for light cleaning tasks

OEL-KLEEN ACTIVE CLEANER 01
Does not attack painted parts, plastic or rubber parts.

Dosing:
Depending on the degree of soiling, concentrate or dilute with water until 1:20. After that, spray thoroughly with clean water.

Do not use with strong heat or sun!
Do not use on aluminum or chrome!

Content	Type	Item No	Unit	Palet
5 L	Can	1010074	1	96
10 L	Can	1010322	1	60
30 L	Can	1010075	1	24

